


Load distribution plate

LVP1Z

Slimline



Your message always supported.

Installation manual

ergoxs.com

ERGO
XS



Loaddistributionplate

LVP1Z


Slimline



Step 1





Step 3-4
Master






Step 5-6
Compact


Step 2




Step 3 Master




Step 4
Master



Step 6
Compact



Step 5
Compact



Blank lined page for writing.

Blank lined page for writing.

